

Biocompatible Opaque MED615RGD

MED615RGD™ is an Ivory opaque, rigid, biocompatible PolyJet™ material medically grade for bodily contact. The printed parts are ideal for medical applications requiring precision and patient contact. The material is designed for medical applications and is suitable for permanent (more than 30 days) contact with intact skin, limited (up to 24 hours) contact with mucosal membranes and breached or compromised surfaces, and limited (up to 24 hours) contact with tissue and bone .

MED615RGD has been evaluated and deemed acceptable for the following biological risks

Test	Standard
Cytotoxicity	EN ISO 10993-5:2009
Irritation	EN ISO 10993-10:2013
Delayed-type hypersensitivity	EN ISO 10993-10:2013
Genotoxicity	EN ISO 10993-3:2014
Chemical characterization	EN ISO 10993-18:2009
USP Plastic Class VI	USP 34 <88>

Property	Standard / Procedure	Value
Tensile Strength	D-638-03	55 – 65 MPa (7,947 – 9,427 psi)
Elongation at Break	D-638-05	10% – 25%
Modulus of Elasticity	D-638-04	2,300 – 3,300 MPa (333.5 – 474.6 ksi)
Flexural Strength	D-790-03	80 – 100 MPa (11,603 – 14,503 psi)
Flexural Modulus	D-790-04	2,300 – 3,300 MPa (333.5 – 474.6 ksi)
HDT @ 0.45 MPa	D-648-06	45 – 50 °C (113 – 122 °F)
HDT @ 1.82 MPa	D-648-07	45 – 50 J/m (113 – 122 °F)
Izod Notched Impact	D-256-06	20 – 30 (0.37 – 0.56 ft-lb/in)
Water Absorption	D-570-98 24HR	1.1 – 1.5%
Tg	DMA E	52 – 54 °C (126 – 130 °F)
Shore Hardness	Scale D	83 – 86 D
Rockwell Hardness Scale	Scale M	73 – 76 M
Polymerized Density	ASTM D792	1.17 – 1.18 (g/cm³) (0.676 – 0.682 oz/in³)
Support Removal Type	–	Waterjet or soluble



Biocompatible Opaque MED615RGD

Property	Standard / Procedure	Value
Sterilization Methods	–	<ul style="list-style-type: none">• Gamma sterilization¹ using a dose of 25–50 kGy• Steam sterilization² for four (4) minutes at 132 °C (270 °F) with fractionated pre-vacuum• EtO sterilization³ using 740mg EtO /l/6h exposure /45C/40-90%RH/degassing 48h-96h/ up to 2 cycles
Biocompatibility	DIN EN ISO 10993-1:2017	Skin contact – permanent (>30 days) Tissue and bone – short term (up to 24 hours) Mucous membrane – short term (up to 24 hours)

System Availability	Minimum Layer Thickness Capability	Support Structure
J735/J750	14 microns (0.00055 in.)	SUP705™ (Waterjet removable) SUP706B™ (soluble) ■ Ivory
J750 Digital Anatomy™ J850 Digital Anatomy™	14 microns (0.00055 in.)	SUP705™ (Waterjet removable) SUP706B™ (soluble) ■ Ivory GelMatrix™ ⁴ (Waterjet removable)
J5 MediJet®	18 microns (0.0007 in.)	SUP710™ (Waterjet removable) ■ Ivory
J5 Digital Anatomy™	18 microns (0.0007 in.)	SUP710™ (Waterjet removable) ■ Ivory

All data provided herein, which is related to consumables, was collected from specific specimens and test conditions and is provided for information only. Characteristics may vary if different specimens and test conditions are applied. Unless expressly provided in writing, no warranties are made and warranties of merchantability or fitness for a particular purpose are expressly disclaimed.

¹ Gamma radiation may result in color change in the part.

² Allow the parts to cool down to room temperature before removing them from the autoclave. Flash autoclave may result in part deformations and changes to the flexural strength.

³ EtO sterilization may result in part deformations and changes to the flexural strength.

⁴ MED615RGD was not tested for biocompatibility with this support material.

For additional information about biological and toxicological assessment and the approved sterilization processes, refer to the [Biocompatible page in Stratasys Support Center](#)

Stratasys Headquarters

7665 Commerce Way,
Eden Prairie, MN 55344
+1 800 801 6491 (US Toll Free)
+1 952 937-3000 (Intl)
+1 952 937-0070 (Fax)

1 Holtzman St., Science Park,
PO Box 2496
Rehovot 76124, Israel
+972 74 745 4000
+972 74 745 5000 (Fax)

[stratasys.com](https://www.stratasys.com)

ISO 9001:2015 Certified

