

A ScanControl+™ Ready Material:

Optimized performance when used with the Neo®800+ printer.

Somos® Taurus™

Stereolithography

A robust material with an unparalleled combination of thermal and mechanical performance.

Somos® Taurus brings the combination of thermal and mechanical performance that previously was not possible with stereolithography materials. Its robustness combined with a charcoal gray appearance makes it ideal for the most demanding functional prototyping and end-use applications. Parts printed with this material are easy to clean and finish. The higher heat deflection temperature of Somos® Taurus increases the number of applications for the part producer and user.

Key Benefits

- Superior strength and durability
- Wide range of applications
- Excellent surface and large part accuracy
- Heat tolerance up to 90 °C
- Thermoplastic-like performance, look and feel

Ideal Applications

- Durable, stiff, tough parts
- Customized end-use parts
- Tough, functional prototypes
- Under the hood automotive parts
- Functional testing for aerospace
- Low volume connectors for electronics



Liquid Properties		Optical Properties		
Appearance	Charcoal	E_c	10.5 mJ/cm ²	[critical exposure]
Viscosity	~350 cps @ 30 °C	D_p	4.2 mils	[slope of cue-depth vs ln (E) curve]
Density	~1.13 g/cm ³ @ 25 °C	E_{10}	111 mJ/cm ²	[exposure that gives 0.254 mm (.010 inch) thickness]



Mechanical Properties		UV Postcure		Thermal Postcure	
ASTM Method	Property Description	Metric	Imperial	Metric	Imperial
D638-14	Tensile Modulus	2,310 MPa	335 ksi	2,206 MPa	320 ksi
D638-14	Tensile Strength at Yield	46.9 MPa	6.8 ksi	49 MPa	7.1 ksi
D638-14	Elongation at Break	24%		17%	
D638-14	Elongation at Yield	4%		5.7%	
D638-14	Poisson's Ratio	0.45		0.44	
D790-15e2	Flexural Strength	73.8 MPa	10.7 ksi	62.7 MPa	9.1 ksi
D790-15e2	Flexural Modulus	2,054 MPa	298 ksi	1,724 MPa	250 ksi
D256A-10e1	Izod Impact (Notched)	47.5 J/m	0.89 ft-lb/in	35.8 J/m	0.67 ft-lb/in
D2240-15	Hardness (Shore D)	83			
D570-98	Water Absorption	0.75%		0.7%	

Thermal/Electrical Properties		UV Postcure		Thermal Postcure	
ASTM Method	Property Description	Metric	Imperial	Metric	Imperial
E831-14	C.T.E. -40 – 0 °C (-40 – 32 °F)	76.5 µm/m °C	42.5 µin/in °F	71.4 µm/m °C	39.7 µin/in °F
E831-14	C.T.E. 0 – 50 °C (32 – 122 °F)	105.3 µm/m °C	58.5 µin/in °F	103.4 µm/m °C	57.4 µin/in °F
E831-14	C.T.E. 50 – 100 °C (122 – 212 °F)	151.9 µm/m °C	84.4 µin/in °F	157.5 µm/m °C	87.5 µin/in °F
E831-14	C.T.E. 100 – 150 °C (212 – 302 °F)	171.4 µm/m °C	95.2 µin/in °F	173.4 µm/m °C	96.3 µin/in °F
D150-11	Dielectric Constant 60 Hz	4.6		4.8	
D150-11	Dielectric Constant 1 KHz	4.2		4.4	
D150-11	Dielectric Constant 1 MHz	3.7		3.5	
D149-09	Dielectric Strength	17.7 kV/mm	451 V/mil	17.3 kV/mm	440 V/mil
D648-16	HDT @ 0.46 MPa (66 psi)	62 °C	144 °F	91 °C	196 °F
D648-16	HDT @ 1.81 MPa (264 psi)	50 °C	122 °F	73 °C	163 °F
D3418-15	Glass Transition Temperature (DSC)	53 °C	127 °F	54 °C	129 °F

These values may vary and depend on individual machine processing and post-curing practices.



stratasys.com
ISO 9001:2015
Certified

Stratasys Headquarters
5995 Opus Parkway,
Minnetonka, MN 55343
+1 800 801 6491 (US Toll Free)
+1 952 937-3000 (Intl)
+1 952 937-0070 (Fax)

1 Holtzman St.
Science Park
Rehovot, 7670401
Israel
+972 74 745 4000
+972 74 745 5000 (Fax)

MATERIAL DATA SHEET SLA

© 2026 Stratasys Ltd. All rights reserved. Stratasys, Stratasys signet, Somos and Taurus are trademarks or registered trademarks of Stratasys Ltd. and/or its subsidiaries or affiliates and may be registered in certain jurisdictions. All other trademarks belong to their respective owners. Product specifications subject to change without notice. MDS_SL_Somos Taurus_0726a